

## ADJUSTMENT

### Common Section Adjustment

Item	Condition	Measurement			Adjustment			Specifications/Remarks		
		Test-equipment	Unit	Terminal	Unit	Parts	Method			
1. Setting	1) Write in freq' and signaling data with EEPROM writer. Source voltage : DC 13.6V POWER SW : OFF VOL VR : Full counterclockwise (CCW). TX-RX unit VR3-5 : Center VR1 : CW VR2, 6 : CCW CN4 (J2) : SET side									
2. PLL	RX	1) Frequency : f <sub>RL</sub>	DVM	TX-RX	TP3			Check	1.5V or more.	
		2) Frequency : f <sub>RH</sub>	Dummy	Rear panel	ANT				8.5V or less.	
	TX	3) Frequency : f <sub>TL</sub> PTT : ON								1.5V or more.
		4) Frequency : f <sub>TH</sub> PTT : ON								8.5V or less.
3. Transmit frequency adjustment	1) Frequency : f <sub>TH</sub> PTT : ON	f. counter Power meter	Rear panel	ANT				Check	f ± 1200Hz	

### Receiver Section Adjustment

Item	Condition	Measurement			Adjustment			Specifications/Remarks															
		Test-equipment	Unit	Terminal	Unit	Parts	Method																
1. Helical	1) Connect the tracking generator to ANT. Tracking generator output : -25dBm Connect the spectrum analyzer to TP1.	Spectrum analyzer  Tracking generator	TX-RX  Rear panel	TP1  ANT	TX-RX	L1, 4  TC1	Check whether required band obtained at max. gain.	<table border="1"> <tr> <td>T4</td> <td>438</td> <td>448</td> <td>458</td> <td>MHz</td> </tr> <tr> <td>T,(N)M</td> <td>450</td> <td>460</td> <td>470</td> <td>MHz</td> </tr> <tr> <td>K4,E,E2, E3,E4</td> <td>415</td> <td>425</td> <td>435</td> <td>MHz</td> </tr> </table>  	T4	438	448	458	MHz	T,(N)M	450	460	470	MHz	K4,E,E2, E3,E4	415	425	435	MHz
T4	438	448	458	MHz																			
T,(N)M	450	460	470	MHz																			
K4,E,E2, E3,E4	415	425	435	MHz																			
2. MCF	1) Frequency : f <sub>RM</sub> SSG output : 0.5μV/-113dBm MOD : 1kHz DEV : ±1.5kHz	DC V.M  SSG	TX-RX	TP2	TX-RX	L7	Alignment to maximum voltage point and 1 turn left the core.																

## ADJUSTMENT

Item	Condition	Measurement			Adjustment			Specifications/Remarks
		Test-equipment	Unit	Terminal	Unit	Parts	Method	
3. Receiving sensitivity	1) Frequency : f <sub>RL</sub> and f <sub>rH</sub> SSG output : 0.3μV/-118dBm MOD : 1kHz DEV : ±1.5kHz	AF V.M Oscilloscope	Rear panel	EXT. SP			Check	SINAD 12dB or more.
		SSG		ANT				
4. Squelch	1) Frequency : f <sub>RM</sub> SSG output : Turn the SSG output 3dB down so that the SINAD sensitivity becomes 12dB.	SSG	Rear panel	ANT	TX-RX	VR1	Set to the point at which squelch just close.	
	2) SSG output : Sensitivity value of 12dB SINAD.						Check	Squelch should open.
	3) SSG output : OFF							Check
5. Acquisition threshold	1) Frequency : f <sub>RM</sub> SSG output : 10μV/-87dBm	LCD					Check	LCD display "0"
	2) SSG output : 1μV/-107dBm	SSG	Rear panel	ANT	TX-RX	VR2	Adjust for LCD display "2".	
	3) SSG output : 0.3μV/-117dBm						Check	LCD display "0"


### Transmitter Section Adjustment

Item	Condition	Measurement			Adjustment			Specifications/Remarks
		Test-equipment	Unit	Terminal	Unit	Parts	Method	
1. APC	1) Frequency : f <sub>TM</sub> PTT : ON	Power meter Ammeter	Rear panel	ANT			Check	28W or more. <b>K4,X,T,T4,E4,(N)M,(N)M2</b> 11W or more. <b>E,E2,E3</b>
					TX-RX	VR6	25W <b>K4,X,T,T4,E4,(N)M,(N)M2</b> 6W <b>E</b> 10W <b>E2,E3</b>	±1W, 7.5A or less. <b>K4,X,T,T4,E4,(N)M,(N)M2</b> ±0.5W, 3.5A or less. <b>E</b> ±0.5W, 4.0A or less. <b>E2,E3</b>
	2) Frequency : f <sub>TL</sub> and f <sub>rH</sub> PTT : ON						Check	20~30W, 7.5A or less <b>K4,X,T,T4,E4,(N)M,(N)M2</b> 4.8~7.2W, 3.5A or less. <b>E</b> 8~12W, 4.0A or less. <b>E2,E3</b>

## ADJUSTMENT

Item	Condition	Measurement			Adjustment			Specifications/Remarks
		Test-equipment	Unit	Terminal	Unit	Parts	Method	
2. Maximum deviation adjustment	1) Frequency : fTM AG : 1kHz/50mV Deviation meter filter HPF : OFF LPF : 15kHz De-emphasis : OFF PTT : ON	Power meter Deviation meter meter Oscilloscope	Rear panel	ANT	TX-RX	VR5	±2.2KHz	±100Hz
			Front panel	MIC				
3. MIC sensitivity adjustment	1) AG : 1kHz/5mV PTT : ON				TX-RX	VR3	±1.5kHz	±100Hz
4. FSK	1) Frequency : fTH AG : OFF Deviation meter filter HPF : OFF LPF : 15kHz CALL + PTT : ON	LCD			TX-RX	VR4	±1.5kHz	±200Hz
							Check	LCD display "10101010"
5. Protection	1) Frequency : fTM and fTH ANT : Open PTT : ON	Ammeter					Check	7.5A or less. <b>K4,X,T,T4,E4,(N)M,(N)M2</b> 3.5A or less. <b>E</b> 4.0A or less. <b>E2,E3</b>

### Adjustment Points (Top View)



- L1, 4 : Helical
- L7 : MCF
- TC1 : Helical
- VR1 : Squelch
- VR2 : Acquisition threshold
- VR3 : MIC sensitivity
- VR4 : FSK
- VR5 : Maximum deviation
- VR6 : APC